



Weatherproof fasteners

WRB w/ drainage channels - joints lapped and taped

1/2 thick cross ventilating battens - placed over WRB

Mesh screen at window head

Window installed per best practice sequence - after WRB

WRB over-lapped over base flashing - skip taped

Penetration flashing integrated into WRB

Flashing tape seals joint at base of wall

Mesh screen at wall base over cross-vented batten (allows air flow through)

Dimpled foundation membrane over damp-proof