

WRB w/ drainage channels - joints lapped and taped

Mesh screen at top of wall over cross-vented batten

Mesh screen at window head

Window installed per best practice sequence - after WRB

3/8" thick cross ventilating battens - placed over WRB

Weatherproof fasteners

Mesh screen at wall base over cross-vented batten (allows air flow through)

WRB over-lapped over base flashing - skip taped

Flashing tape seals joint at base of wall

