

Weatherproof fasteners

1/2 thick cross ventilating battens- placed over WRB

WRB over-lapped over base flashing - skip taped

Flashing tape seals joint at base of wall

The miracles of science™

OU POU

veik

OU POU  
veik  
D inWrap

veik www.TYVEK.com  
The miracles of science™

WRB w/ drainage channels - joints lapped and taped

Mesh screen at window head

Window installed per best practice sequence- after WRB

Penetration flashing integrated into WRB

Mesh screen at wall base over cross-vented batten (allows air flow through)

Dimpled foundation membrane over damp-proof

