



Trunk saddle - easily screws in the flex for air tightness



Collar - Screwed to the 2 x 4 and then the diffuser is placed after the sheet rock is installed.