



DuPont
ThermaWrap w/
min 3/4" airspace

Mortar net at
base of wall

Base Butyl flashing

Leave every 6th
mortar joint open-
Install screen
material

Metal base flashing
lapped under
ThermaWrap and
secure to base
flashing