

Technical Tip

AdvanTech® Flooring over Concrete Slabs

There are two methods used to attach AdvanTech® panels to concrete slabs. Both methods require the preparation of the slab.

Slab Preparation

Cover the slab with minimum 6 mil polyethylene sheeting. The polyethylene sheet should be spot glued to the slab with a polyurethane based adhesive that will bond to both concrete and plastic. All joints in the polyethylene sheeting should be lapped a minimum 4". These laps should also be glued to ensure an adequate moisture seal. The plastic should extend up the sides of the walls a few inches. Once the AdvanTech panels are installed, the excess plastic can be trimmed flush.

Method 1 - Application direct to slab

- After preparing the slab as described above, place panels directly on polyethylene sheeting
- Space panels 1/8" at 4-foot. The T&G edge is self-spacing.
- Fasten panels with masonry nails, concrete fasteners or powder-actuated fasteners.
- Place fasteners 3/8" from panel edges.
- Space fasteners no more than 6" o.c. at panel edges and no more than 12" o.c. in the field. Field fastener lines should be no more than 16" apart.

Method 2 - Application to Sleepers

- After preparing the slab as described above, install 2x4 sleepers. The recommended sleeper spacing is 16" o.c.
- Fasten sleepers to concrete slab with masonry nails, concrete fasteners or powder-actuated fasteners.
- Lay panels on joist system with long dimension across joists. All panels should cover at least 3 sleepers.
- Space panels 1/8" at 4-foot ends. The T&G edge is self-spacing.
- Fasten AdvanTech panels with #9 wood screws or 8d ring shank, screw shank or common nails that penetrate sleepers at least 1-inch. For 23/32" thick AdvanTech, fasten panels to sleepers with 6d ring shank, screw shank or common nails.
- Place fasteners 3/8" from panel edges.
- Space fasteners no more than 6" o.c. at panel edges and no more than 12" o.c. at field supports.

AdvanTech is a registered trademark of Huber Engineered Woods LLC