

## Professional Grade Adhesives & Sealants



- Designed to fasten cellular PVC trim to the exterior of a home
- Fast grab formula designed to lend an extra set of hands on the job
- Durable polyurethane strength
- Water & Weatherproof

OSI® TRIMTeQ™ TEQ Mount is a mounting adhesive, specifically designed to fasten cellular PVC trimboard to the exterior of a home. It features an innovative instant grab formula designed to lend an extra set of hands on the job. OSI® TEQ Mount's premium formula delivers durable polyurethane strength and will last as long as the surfaces it joints together. It cures in 24 hours and is water & weatherproof and bonds to a wide variety of building materials.





©Henkel Corporation 2010/41990



Visit www.osipro.com or call 1-800-624-7767 for a comprehensive installation manual and training DVD.



# **Professional Grade Adhesives & Sealants**

## **Description**

OSI® TRIMTeQTM TEQ MountTM Mounting Adhesive, is specifically designed to fasten cellular PVC trimboard to the exterior of a home. It features an innovative fast grab formula designed to lend an extra set of hands on the job. OSI® TEQ Mount's premium formula delivers durable polyurethane strength and will last as long as the surfaces it joins together. It cures in 24 hours and is water & weatherproof and bonds to a wide variety of building materials under any conditions.

#### Recommended for

Fastening cellular PVC trimboard to the exterior of the home. Bonds most common construction materials such as wood, treated wood, hardwood flooring, concrete, stone, marble, slate, masonry, brick, foam insulation of all sorts, carpets, metal, lead, cement-based products, ceramic, fiberglass, drywall and mirrors.

#### Not recommended for

Polystyrene Tub Surrounds

Water submersion applications

Polystyrene, polyethylene or polypropylene.

Certain materials such as rubbers and plastics may have bonding difficulties. Test before use.

## Typical Uncured Physical Properties

Color: Grey

Appearance: Thick paste
Base: Polyurethane
Viscosity: 18,000 cps
Specific Gravity: 1.30

VOC Content: 22 g/L (1.7% by weight)

Shelf Life: 12 months from date of manufacture

(unopened)

Application Temperature: Apply above 40°F (°C)

Open Time: 20 Minutes

Dry Time: 24 to 48 hours @ 78° F (25°C) and

50% RH Cure time is dependent upon temperature, humidity, porosity of substrate and amount adhesive used.

Odor: Minimal

Lot Code Explanation: 3L**0028**HP11

0=last digit of year of manufacture

028=day of manufacture based on 365 days per year



Visit **www.osipro.com** or call **1-800-624-7767** for a comprehensive installation manual and training DVD.

#### **Directions**

Tools Typically Required: Utility knife, caulking gun, tool to puncture cartridge seal, plant mister bottle containing water.

Safety Precautions: Wear gloves. Cured adhesive on bare skin will not come off immediately with washing and will cause skin to darken. Cured adhesive and discolouration will come off in about 3 days.

**Preparation:** Use above 40°F (5°C). Surfaces must be clean and free of frost, standing water, grease, dust and other contaminants. Pre-fit all materials and protect finished surfaces. Cut nozzle at a 45° angle to desired bead size and puncture inner seal. Be very careful not to allow  $OSI_{\mathbb{R}}$  TeQ Mount<sup>TM</sup> to cure on a finished surface.

Application: Apply adhesive to one surface of the material being bonded. Press the surfaces firmly together. Materials may be repositioned within 20 minutes after applying the adhesive. If bonding two non-porous surfaces (such as foam, metal and fiberglass), add water in the form of a very light or atomized spray from a plant mister bottle to the extruded adhesive. The repositioning time will then be reduced to less than 15 minutes. Use mechanical support for 24 hours while the adhesive cures. For installing PVC trimboard to the exterior of the home, use OSI® TeQ Fasteners™ following the application of the adhesive to ensure a quality installation. Consult the manufacturer's instructions for complete installation information.

Clean-up: Clean tools and excess uncured adhesive residue immediately with mineral spirits following solvent manufacturer's precautions. Clean tools in a well-ventilated area, away from sparks and flames. OSI® TeQ Mount $^{\text{TM}}$  must be removed mechanically once cured.

## Coverage

For a 10 fl. oz. cartridge:

A 1/4" (6 mm) bead extrudes approximately 30.6 ft (9.35 m). A 3/8" (9.5 mm) bead extrudes approximately 13.6 ft (4.1 m).

### **Storage and Disposal**

Not damaged by freezing. After completion of work, seal cartridge nozzle tightly with aluminum foil. Wrap the foil tightly around the nozzle and seal it with tape. Applying petroleum jelly around the opening before sealing with aluminum foil can create a more airtight seal. Product cures with exposure to moisture. Use an approved hazardous waste facility for disposal.

#### **Disclaimer**

The information and recommendations contained herein are based on our research and are believed to be accurate, but no warranty, express or implied, is made or should be inferred. Purchasers should test the products to determine acceptable quality and suitability for their own intended use. Nothing contained herein shall be construed to imply the nonexistence of any relevant patents or to constitute a permission, inducement or recommendation to practice any invention covered by any patent, without authority from the owner of the patent.



Henkel Corporation Professional and Consumer Adhesives Phone 1-800-624-7767 Fax (440) 250-7873 www.henkel.com www.osipro.com